CAUTION: To reduce the risk of fire or burns do not disassemble, crush puncture, or short external contacts. Do not dispose of in fire or water. Replace only with the same or equivalent type recommended by the manufacturer. Use only supplied AC adapter for charging. Dispose of used batteries according to the manufacturer instructions. Do not expose to high temperatures above 60°C (140°F). Keep away from children.
Rechargeable Battery
TYPE: M5R2H (312-1387)
FOR: INSPIRON 14 3421/INSPIRON 14R M421/INSPIRON 15 3521/INSPIRON 15R 3521/ Rating:11.1V, Power 44Whrs60
INSPIRON 17 3721/ INSPIRON 17R 5721/5737RD 7421/7537RD 7521/ Battery