



Warning
Risk of fire or burning. Do not disassemble, short circuit, heat, crush, puncture or modify the battery, wiring or terminals.
Do not dispose of in fire or subject to high temperatures (above 140°C).
Do not charge or recharge the battery from the secondary source.
Do not use the battery in a device that is not approved for use with this battery.

BE NEEB



Warning
Risk of fire or burning. Do not disassemble, short circuit, heat, crush, puncture or modify the battery, wiring or terminals.
Do not dispose of in fire or subject to high temperatures (above 140°C).
Do not charge or recharge the battery from the secondary source.
Do not use the battery in a device that is not approved for use with this battery.



CE

