DC 11.1V 4400mAh/49Wh
Replace: BTY-S11
CAUTION
Do not dispose of in fire, but keep the battery away from fire. Do not destroy (short circuit) the positive(+) and the negative(-) terminals. Never attempt to disassemble or reassemble the battery pack. Do not use chargers other than the designated one to charge the battery pack.